




IMPORTANT SAFETY INFORMATION

- Young children can be strangled by loops in pull-cords, chains and tapes, and cords that operate the product.
- To avoid strangulation and entanglement, keep cords out of the reach of young children.
- Cords may become wrapped around a child's neck.
- Move beds, cots and furniture away from window covering cords.
- Do not tie cords together.
- Make sure cords do not twist and create a loop.
- In the even of the control chain being broken, the chain may release small parts which could be swallowed and cause internal asphyxiation of a child.
- Headrails of internal blinds with pull cords shall not be installed at less than 1.5m from the floor



Child Safety Device



- Read these instructions carefully before installing and using the device. Children can be strangled if the device is not installed correctly. Keep the instructions for future reference.
- Use of additional safety devices helps reduce the risk of strangulation but cannot be considered entirely foolproof.
- The Safety Chain device reduces the hazards of strangulation or entanglement by limiting access to the cord or bead chain. Anchor the device with the cord or bead chain to the wall or floor, so young children cannot pull the cord or bead chain around their necks. Always use this device to keep cords or chains out of reach of children

Mounting the Child Safety Clip

The child safety clip is designed for fitting onto an adjacent surface to the blind in order to eliminate a free hanging loop.

1. Pull the chain up into the child safety clip
2. Place the child safety clip onto an adjacent wall or where the clip is fixed in such a way that the loop cannot be easily reached.
3. Ensure the control chain is pulled tight.
4. Screw the child safety clip in place